CABINET PARTS

REFRIGERATOR

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		LITERATURE PARTS
	LIT2205958	Use & Care Guide
	LIT2216656	Service & Wiring Sheet
	LIT2219761	Energy Label
	LIT628370	Modular Icemaker Service Sheet
2	2174748	Front Roller (2)
3	3400517	Screw
4	2196236	Roller (Rear) (2)
5	489427	Screw
6	2155013	Clip, Grille
7	489478	Screw
8	2186443	Housing, Water Filter
9	2209697	Shim
10	2203771	Hinge Top (RC)
12	8281227	Screw
13		Hinge Cover
	2203407W	White
	2203407T	Biscuit
	2203407B	Black
14	2217075	Hinge Bottom (2)
15		Filler, Wrapper
	2196094	White
	2196150	Biscuit
	2196097	Black
16		Grille
	2198467W	White
	2198467T	Biscuit
	2198467B	Black
	2198467TG	Tempest Gray
17	489497	Screw
18	489464	Screw
19	940139	Drain Fitting
20	1108438	Extension Tube
21	1108439	Clip, Drain Tube
22	2203220	Water Filter
23	2204202	Cover, Unit
24		Hinge Cover
	2203408W	White
	2203408T	Biscuit
	2203408B	Black
25	549193	Clamp, Service Cord
26	489084	Screw
27	2155311	Door Closer, Lower Cam (2)
28	489483	Screw
29	489500	Screw
30		Cap, Water Filter
	2186494W	White
	2186494T	Biscuit
	2186494B	Black
31		Cabinet (Not A Serviceable Part
32	2203770	Hinge Top (FC)

REFRIGERATOR LINER PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2194744	Escutcheon, Meat Pan Control
3	2182757	Slide Meat Pan Control
4	2182147	Louver
5	2171846	Release Valve
6	8281158	Screw
7	2205813	Strap
8	2196483	Stud, Assembly
9	2206270	Shelf Ladder
10	487539	Screw
11	486298	Screw (2)
12	2179404	Rack, Wine & Egg
13	1123919	Bracket Retainer
14	489290	Screw
15	2209753	Air Diffuser Assembly
16	2152019	Air Diffuser Cover
17	2150331	Cover, Conduit
18	2162085	Socket
19	2209687	Reservoir
20	527949	Light Bulb
21	2206269	Light Lens
22	488280	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	2194736	Shelf Assembly, Glass Sliding (2)
2	2196233	Snack Bin
3	2209698	Cover, Crisper
4	2204485	Shelf, Flip−Up
5	2174150	Glass, Cover
6	2179259	Glass, Cover
8	2217039	Cover, Meat Pan
9	2195975	Frame, Shelf (2)
10	2196232	Crisper Pan
11	2179343	Front, Crisper Pan
12	2179342	Slide, Humidity Control
13	2194913	Trim, Handle
14	2196231	Meat Pan
15	2182730	Egg Bin
18	2179350	Deflector
19	2194906	Trim, Handle
20	2196485	Stud Assembly
21	2196483	Stud Assembly
22	2206347	Shelf, Snack Bin
23	3400894	Screw
24	2179243	Trim, Handle
25	8281158	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
6	2181761	Basket, Tall
7		Track, Basket−Dual
	2211740	Right Side
	2211741	Left Side
9	2211743	Shelf, Slide Out Upper
12	2195904	Basket, Front
13		Shelf Track
	2181760	Right Side
	2181759	Left Side
14	2212343	Shelf
15	2181762	Basket, Sloped
16	486298	Screw
17	842534	Clip, Air Duct
19	2198587	Cover, Emitter
22	2198635	Spring
23	2198634	Pin
25	1115373	Switch, Rocker Arm
26	2198585	P.C. Board Emitter
27	2212319	Cover, Ice Maker
28	2212321	Slide, Ice Maker Mounting
29	489478	Screw
30	489214	Screw
31	2198665	Tube, P.C. Board
32	2162085	Light Socket
33	527949	Light Bulb
34	8281185	Screw
35	2198633	Flipper
36	2198588	Cover, Receiver
37	2198637	Slide, Ice Maker Shut Off
38	2198586	P.C. Board, Receiver
39	2198643	Lens
41	2212376	Light Lens
42	2198641	Bracket, Ice Maker Cover
43	2155597	Socket, Light
44	527949	Light Bulb
45		Ladder
	2212315	Left Side
	2212316	Right Side
46	2198639	Shield, Wiring

MOTOR AND ICE CONTAINER PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01

(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2212302	Ice Bin
2	2212301	Crusher Bin
3	2212342	Auger
4	2212382	BLade, Stirring
5	1119007	Spacer, Flat (6)
6	2212307	Cover, Crusher
7	1119013	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2198601	Blade, Fixed
10	1119012	Blade, Rotary
11	2198602	Block, Blade
12	489229	Roll Pin
13	1119006	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2198604	Coupling
17	8281164	Screw
18	3400065	Screw
20	2212308	Latch, Bin
21	2198608	Spring, Latch
23	8281163	Screw
24	2212369	Holder
25	2198627	Coupling, Bottom
26	2198628	Seal
27	2212370	Washer
28	2198666	Pin
29	2198607	Spring
30	2198624	Drive Shaft
31	2212304	Bracket, Motor
32	2212363	Dispenser, Motor
33	2212305	Cover
35	489478	Screw
36	2212365	Sleeve, Coupling

REFRIGERATOR DOOR PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item #8)
	2207033W	White
	2207033T	Biscuit
	2207033B	Black
	2207033S	Stainless
2		Jewelry, Handle
	2207010G	Gold
	2207010SN	Satin Nickel
3	2177105	Door, Compartment
4	2156022	Trivet, Shelf
5	489491	Screw
6	2179607	Shelf Bin (3)
7		Trim, Door−Bottom
	2217186W	White
	2217186T	Biscuit
	2217186B	Black
	2217186TG	Tempest Gray
8		Door Gasket, Magnetic (Service)
	2159073	Mist Beige
	2159081	Black
9		Handle
	2217185W	White
	2217185T	Biscuit
	2217185B	Black
	2217185TG	Tempest Gray
10	3400012	Screw
11	2195327	Clip (4)
13		Trim, Door−Top
	2217191W	White
	2217191T	Biscuit
	2217191B	Black
	2217191TG	Tempest Gray
14	2182178	Door Closer, Upper Cam
15	489420	Screw
16		Bracket, Door Stop
	2200082	Chrome
	2200082B	Black
20	3400852	Screw
21		Nameplate
	2207087W	White
	2207087T	Biscuit
	2207087B	Black
	2207087TG	Tempest Gray

FREEZER DOOR PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes Item #8 And Dispenser Front Parts)
	2212360W	White
	2212360T	Biscuit
	2212360B	Black
	2212360S	Stainless
2		Handle
	2217185W	White
	2217185T	Biscuit
	2217185B	Black
	2217185TG	Tempest Gray
3	8281149	Screw
4	489491	Screw
5	2195327	Clip (4)
6	2156021	Trivet, Shelf (4)
7	2207010G	Jewelry, Handle
8		Door Gasket, Magnetic (Service)
	2159072	Mist Beige
	2159080	Black
9	2212375	Trim, Door Shelf
10	3400012	Screw
11		Wire Harness
	2207225	For W, B, & T Mls.
	2207226	For Stainless
12	2182179	Door Closer, Upper Cam
13	489420	Screw
14	2200082	Bracket, Door Stop
16	2154473	Connector
17		Trim, Door−Bottom
	2217186W	White
	2217186T	Biscuit
	2217186B	Black
	2217186TG	Tempest Gray
18		Trim, Door−Top
	2217191W	White
	2217191T	Biscuit
	2217191B	Black
	2217191TG	Tempest Gray
21	3400852	Screw

DISPENSER FRONT PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	3196165	Screw
3	2194719	Retainer, Levers
4	2180209	Spring, Torsion
5	2196195	Pin
6	2180352	Door, Ice
7	2206423	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2207048W	White
	2207048T	Biscuit
	2207048B	Black
	2207048TG	Tempest Gray
10	2180225	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2203562W	White
	2203562T	Biscuit
	2203562B	Black
	2203562TG	Tempest Gray
12	2180224	Guide, Ice
13	2180200	Lamp Holder
14	2162361	Switch (2)
15	2183771	Bracket, Control
16	3406124	Bulb, Light
17		Lever, Water Dispenser
	2203561W	White
	2203561T	Biscuit
	2203561B	Black
	2203561TG	Tempest Grey
18		Switch Assembly (Not Available, Order #23)
19		Overlay, Front Cover (Not Available, Order #23)
20	2198622	Wire Assembly
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 18, 19, 20 & 21)
	2207281W	White
	2207281T	Biscuit
	2207281B	Black
	2207281TG	Tempest Gray
24	625834	Spacer, Switch (2)
25	2195051	Strain Relief
26	3400065	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	486692	Speed Nut
2	2190685	Fan, Blade
3	2204484	Condenser Assembly
4	489464	Screw
6	489099	Screw
7	2149293	Heat Shield And Drain Pan
8	2204238	Tube Suction
9	2158826	Dampner
10	2216914	Clip, Condenser
11	2211760	Tube, Condenser to Heat Loop
12	4387731	Cover (Service Compressor Only)
13	4387767	Overload (Service Compressor Only − Includes Relay)
14	2161324	Clip, Defrost Heater
16	2212193	Start−Device, Combination (Start Relay and Overload for Production Compressor Only)
17	2169373	Capacitor (Production
	4387764	(Service)
20	2182057	Unit Cover, Bottom
21	489396	Clip
22	2164518	Evaporator
24	2188537	Motor, Fan
25	1105523	Tray, Evaporator
26	2216406	Harness, Wire
27	2199167	Drier
28	2212191	Compressor (Includes Items 12, 13, 17 & 27)
30	2160500	Frame, Unit Mounting
32	2181929	Bracket, Fan Motor
33	2188174	Heater, Defrost
34	2161330	Clip
35	2196155	Bi−Metal, Defrost
37	489473	Screw
39	2183042	Grommet (4)
40	489340	Screw
41	2196202	Air Baffle
42	2155547	Clip, Heat
48	2149717	Unit Mounting Rail
49	8281232	Screw
50	2186496	Guard, Fan
51	2161302	Sleeve
52	2172840	Wire Tie
53	489427	Screw
54	850145	Wire Connector
55	489478	Screw
59	2208280	Clip, Wire & Tube
63	2209709	Connector, Water Tube

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

5.0 oz.
(R−134)

ICEMAKER PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2198677	Connector, Water Tube
2	2198578	Fitting, Water Tube
3	2186493	Tube, Filter Outlet
4	2200202	Tube, Filter Inlet
5	628379	Clip, Fuse
6	2200083	Nut, Compression
7	2216964	Tube, Water
9	489478	Screw
10	2212374	Valve, Solenoid
11	627018	Nut, Compression
14	489385	Tube, Clamp
18	2174358	Cover
19	488649	Screw
20	2212351	Mold & Heater Assembly (Also Order 542638 Silicone Grease)
22	628356	Cup−Water Fill
23	2212320	Ejector
24	2212318	Ice Striper
25	2194712	Support
26	627796	Retainer, Thermostat
27	627985	Thermostat (Also Order 542369 Cement Alumilastic)
28	489322	Screw
30	489276	Screw
32	2212381	Harness, Wiring
33	2212317	Bracket, Icemaker Mounting
35	628399	Module Assembly (Includes Items 37 & 38)
37	628398	Motor
38	489136	Screw
40	1129179	Nut, Compression

CONTROL PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	2200136	Control Box
2	1110629	Mounting Bracket
3	3196537	Screw (4)
4	2149705	Light Switch
5	2196001	Tube Barrier
6	2188159	Adaptive Defrost Control
7	489398	Screw (2)
8	940014	Hole Plug
9	2198202	Thermostat
10	487869	Screw
11	2182195	Cam Assembly
12	1110560	Bearing Body
13	2200096	Cover, Light Lens
14	2196062	Clip, Damper Control
15	1110559	Pivot Arm
16	627068	Screw
17	2162085	Light Socket
18	489398	Screw
19	527949	Light Bulb
20	2211318	Control Box Harness
21	1115374	Clip, Wiring
22	1115375	Clip, Wiring
23	1123960	Connecting Rod
24	489285	Fastener, Push−On
25	2212073	Escutcheon, Control Box
26	2182111	Thermostat Knob
27	2197871	Knob, Air Control
29	489203	Spring Washer
30	2200097	Retainer, Light Lens
31	2203384	P.C. Board, Filter Indicator
32	487869	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW PARTS

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	2182119	Fan Scroll
2	2155590	Retainer, Fan Motor
3	2198595	Air Scoop
4	2212377	Air Duct, Upper
5	2212313	Air Duct Freezer
7	2162404	Fan Motor
8	2169142	Fan Blade
10	2176759	Fan Grommet (2)
12	2206504	Harness, Fan Evaporator and Heater, Bi−Metal
13	2155788	Gasket Cover
14	2172840	Wire Tie
16	2203875	Gasket
17	2212314	Cover, Evaporator
18	489355	Screw
21	489478	Screw
22	2203595	Support, R.S
23	2203596	Support, L.S

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PARTS NOT ILLUSTRATED

For Models: GS2SHAXKQ01, GS2SHAXKT01, GS2SHAXKB01, GS2SHAXKS01
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch−Up Material

*350942	Primer, White (13 Oz. Spray Can)
*350939	Enamel, Black (13 Oz. Spray Can)
*350930	Enamel, White (13 Oz. Spray Can)
*350956	Enamel, Almond (13 Oz. Spray Can)
*4392901	Enamel, Biscuit (13 oz. Spray Can)
72017	Brush Touch−Up Kit (White)
72107	Brush Touch−Up Kit (Almond)
72032	Brush Touch−up kit (Black)
4392899	Brush Touch−Up Kit (Biscuit)

*__Caution:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

Refinishing Material

799340	Enamel, Black (1 Qt. Uncut)
799344	Enamel, White (1 Qt. Uncut)
978883	Enamel, Almond (1 Qt. Uncut)
4392900	Enamel, Biscuit (1Qt. Uncut)

Illus. No.	Part No.	DESCRIPTION

Miscellaneous

212643	Sealer, Gum (4 Feet)
479502	Tape, Vinyl (3/4 x 108")
876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")
876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
978941	Insulation, Fiberglass (63−1/2" x 35−1/2" X 2−5/8)
876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
505587	Sealer, Mastic (1 Qt.)
503695	Cork, Sealer (1/4 Pound)
511873	Touch−Up, White Porcelain (2 Oz.)
542638	Grease, Silicone (1/2 Oz.)
542639	Cement, Alumilastic (1−1/4 Oz.)
606755	Bag, Insulation (36−5/8" x 46")
799833	Kit, Evaporator Repair (Aluminum Epoxy)
833938	Kit, Terminal Connector
2212303	Ice Container−Crusher Assembly

TORX SCREW WRENCH

1117510	Torx Key

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST